
MMI with radio and Bang & Olufsen sound system from January 2011




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




- Radio R
- Fuse panel 3
- Fuse 7 (on fuse panel F)
- Double connector
- 10-pin connector
- Ground connection in luggage compartment, left
- Ground connection 16 (in main wiring harness)
- Refer to applicable wiring diagram for fuse positions
- Fiber optic cable

### Radio

R	Radio
R11	Antenna
R24	Antenna amplifier, Rear window, lower left
R112	Antenna amplifier 3
R170	Satellite antenna
R183	Digital radio antenna
R216	Roof antenna
T2bt	Double connector
T2bw	Double connector
T2dl	Double connector
T2dm	Double connector
T2hc	Double connector
T4an	4-pin connector
T4ao	4-pin connector
T4ba	4-pin connector
*	USA only
*2	Only for vehicles without TV reception
*3	Only for vehicles with TV tuner





R Radi

R47 Central locking and anti-theft alarm system antenna


R93 Radio antenna 2

R111 Antenna amplifier 2, Rear window, upper left

T2co Double connector

T4aq 4-pin connector

T4ba 4-pin connector



30

31

ws = white
sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
vi = lilac
ge = yellow
or = orange
rs = pink

40

41


4G2-037040413


Wiring Diagram



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

4





gn/vi

gn/vi

J794

0.35

gn/vi

gn/vi

T32b /32

J533

(B444)

R164

0.35

0.35

0.35

52

T6e √2 0.35

0.35

0.35

54

T6e

T6e

R141

4G2-037050413

T6e √3

**R**74

53

white

br = brown gn = green bl = blue gr = grey


= lilac = lilac i = lilac e = vellow

ge = yellow or = orange rs = pink

# Digital sound system control module, Center speaker, Left effects speaker, Right effects speaker


```
J525 Digital sound system control module
R208 Center speaker
R209 Left effects speaker
R210 Right effects speaker
R219 Center speaker 2
T2gw Double connector
T2kh Double connector
T2kk Double connector
T2kk Double connector
T171 17-pin connector, in the left A-pillar connector station
```

38-pin connector



## Digital sound system control module, Left rear treble speaker, Right rear treble speaker

- J525 Digital sound system control module
- R14 Left rear treble speaker
- R16 Right rear treble speaker
- T2gz Double connector
- T2hb Double connector
- T27c 27-pin connector, on the left B-pillar T27d 27-pin connector, on the right B-pillar
- T38 38-pin connector



Digital sound system control module, Left front bass speaker, Left front midrange speaker, Right front midrange speaker

J525 Digital sound system control module

21 Left front bass speaker

R23 Right front bass speaker

R103 Left front midrange speaker

R104 Right front midrange speaker

T4dg 4-pin connector

T4dh 4-pin connector

T23a 23-pin connector, on the left A-pillar


T23b 23-pin connector, on the right A-pillar

T27a 27-pin connector, on the left A-pillar

T27b 27-pin connector, on the right A-pillar

T38 38-pin connector

from June 2011



rotected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

= white

= lilac

= white = black = red = red

= brown

= green

= blue

= grey

= lilac


= lilac = yellow

= pink

= orange

# Digital sound system control module, Left front treble speaker, Right front treble speaker

- J525 Digital sound system control module
- R20 Left front treble speaker
- R22 Right front treble speaker
- T5n 5-pin connector
- T5o 5-pin connector
- T17I 17-pin connector, in the left A-pillar connector station
- 38 38-pin connector
- V344 Left front treble speaker motor
- V345 Right front treble speaker motor





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


### ( J525 **U**<sub>T32e</sub> T32e /28 T32e /22 T32e /23 T32e /24 T32e /26 0.35 0.35 0.35 0.35 0.35 0.35 0.35 0.35 0.35 vi/ge (397) 0.35 0.35 0.35 T8bb T8bb T8bb T8bb Т8ьь 0.35 vi/ge 1.0 0.35 0.35 0.35 T17a T17a = white = black 0.35 1.0 0.35 0.35 0.35 0.35 0.35 0.35 0.35 0.35 vi/ge = red mmerc I purposes, in part or in wh nent. Copyright bgrAUD≒Acgreen J623 = blue **J**931 = grey R142 R143 R144 R145 = lilac \*2 = lilac = yellow 124 113 114 115 116 117 118 119 120 121 122 123 = orange or [4G2-037100413] rs = pink

### Digital sound system control module, Left center microphone, Left rear microphone

- J525 Digital sound system control module
- J623 Engine control module
- J931 Subframe mount control module
- R142 Left center microphone
- R143 Right center microphone
- R144 Left rear microphone
- R145 Right rear microphone
- T8bb 8-pin connector, on the left C-pillar
- T17a 17-pin connector, Left plenum chamber E-box connector station
- T32e 32-pin connector
- 397 Ground connection 32 (in main wiring harness)
  - Depending on equipment
- \*2 Refer to applicable engine wiring diagram


Digital sound system control module, Digital sound system control module 2

- J525 Digital sound system control module
- J787 Digital sound system control module 2
- T32e 32-pin connector
- T32f 32-pin connector



### Digital sound system control module, Digital sound system control module 2

- J525 Digital sound system control module J787 Digital sound system control module 2
- ST2 Fuse panel 2
- SF11 Fuse 11 (on fuse panel F)
- T32e 32-pin connector
- T32f 32-pin connector
  - \* Refer to applicable wiring diagram for fuse positions



No. 37 / 13

### Digital sound system control module 2, Right rear mid-bass speaker, Subwoofer

J787 Digital sound system control module 2

R159 Left rear mid-bass speaker

R160 Right rear mid-bass speaker

R211 Subwoofer

T2go Double connector

T2gv Double connector

T2ha Double connector

T27c 27-pin connector, on the left B-pillar

T27d 27-pin connector, on the right B-pillar

T32f 32-pin connector

